

# KRATOS

MECHANICAL BACKLIT KEYBOARD

GET READY TO FIGHT!




USER GUIDE



# KRATOS

MECHANICAL BACKLIT KEYBOARD

GET READY TO FIGHT!



1). WASD/Arrows keys

2). Multimedia keys

3). Gaming mode

4). Key Lighting button

5). WASD/Arrows key lighting button

6). Lighting setup button

7). Macro keys

8). Function button

## TECHNICAL SPECIFICATIONS

**TYPE:** MECHANICAL

**KEY SWITCH TYPE:** RED / BLUE / BROWN (Khailh)

**KEYS:** 109

**OPERATION FORCE:** 60±20G

**INTERNAL MEMORY:** 128 kb

**CONNECTION:** Gold Plated USB

**CABLE LENGHT:** 180 cm

**DIMENSIONS:** 473 x 166 x 37 mm


**WEIGHT:** 1,310 Kg

**COMPATIBILITY:** WindowsXP/Vista/7/8

## SHORTCUT KEYS ON KEYBOARD




## MACRO KEYS



## EXTRA SHORTCUTS




## LIGHTING MODE KEYS (these functions don't need FN key)





## LEDs FUNCTIONS

### LIGHT INTENSITY



Backlight brightness adjustable in six different levels:

- |                    |                   |
|--------------------|-------------------|
| 1: Led OFF         | 4: 75% brightness |
| 2: Breathing mode  | 5: 50% Brightness |
| 3: 100% Brightness | 6: 25% Brightness |

These configurations is applicable on all of the other modes of backlight

### LIGHT MODES



Backlight adjustable in four differents modes:

- 1: Led OFF
- 2: Light all keys
- 3: Lighting animation mode (Circle way)
- 4: Custom light mode

#### Custom light mode configuration (Within the lighting mode 4)

**Step 1:** Press FN + Light mode key (gaming light indicator start to flicker)

**Step 2:** Press the keys you want to turn on / turn off

**Step 3:** Press FN + Light mode key to exit the customization

### WASD / ARROWSLIGHT MODES



Backlight brightness adjustable in six different levels:

- |                    |                   |
|--------------------|-------------------|
| 1: Led OFF         | 4: 75% brightness |
| 2: Breathing mode  | 5: 50% Brightness |
| 3: 100% Brightness | 6: 25% Brightness |

## SOFTWARE INSTRUCTIONS

### INSTALLATION

- 1: Download the drivers from the productsheet of our website: [www.kromgaming.com](http://www.kromgaming.com)
- 2: Open the RAR file and click the executable file, the installation will start automatically
- 3: Choose the folder to install the software and the installing configuration, then press "install"
- 4: After the installation is finished you can use the kratos software to configure the keyboard

### CONFIGURATION

the software are divided in four Menus:

#### MAIN SETTINGS - Here you can assign a different function for each key

- 1: Click on any key
- 2: Choose between multimedia, keypad key or insert a preset value
- 3: Press "accept" in the bottom menu to apply the changes

#### MACRO SETTINGS - Here you can assign a function for each macro key

- 1: Click on any key on the right menu
- 2: Choose between close, default or macro manager to asing a function on this macro key
- 3: Press "accept" in the bottom menu to apply the changes

#### BACKLIGHT - Offers three sub-menu options to configure the backligt

**Sub-menu 1:** Configure the brightness intensity for gaming and normal keys

**Sub-menu 2:** Activates the animation light mode and configures its speed

**Sub-menu 3:** Activates the custom light mode and choose the keys you want to turn on / off

#### ADVANCED - Configuration of other functions of the keyboard

- |                            |                            |
|----------------------------|----------------------------|
| - Anti-ghosting mode       | - Startup autorun on / off |
| - Gaming mode              | - Language                 |
| - WASD/arrow keys exchange | - Upgrade the software     |



## ■ SOFTWARE INSTRUCTIONS

### ■ OTHER FUNCTIONS

■ **PROFILES** - The software allows to create five different profiles. The profiles can be:

- 1: Created
- 2: Loaded
- 3: Saved
- 4: Edited

You can keep assigned 5 profiles in the software for easy access and save more on your pc.

■ **MACRO MANAGER** - Here you can create and storage the different macro functions

#### ■ Create a macro manager

- Step 1:** Click on the macro manager right button
- Step 2:** Press "new macro", assign a name and then press "start input" to start to create the macro function
- Step 3:** After the sequence is created, you can delete /include the delays or add more function keys from the right panel (multimedia, mouse or keypad functions)
- Step 4:** Press "new macro" to create a new sequence or press "ok" to exit the macro manager menu

■ **RESTORE TO DEFAULT** - Reset the functions and configuration created and restart the software to default settings

- 1: Click on the "Recovery" button on the left side of the bottom menu
- 2: Press "yes"
- 3: The software functions are restored to factory default

**NOTE:** The "restore to default" button affects to the five profiles you have active in the software. To keep the profile, save it in your pc before restore and then load it in one of the profile buttons.

## ■ WARRANTY

### ■ Who the warranty Protects:

This warranty is valid to the original purchaser only.

### ■ What the warranty protects:

For your warranty claims, please contact Nox xtreme overseas distribution partners in your country. Find the distribution partner list at [www.kromgaming.com](http://www.kromgaming.com)

■ **Warranty:** 2 years from purchasing date. (Depending on the laws of each country)

■ **URL:** [www.kromgaming.com](http://www.kromgaming.com)

■ **E-mail:** [support@kromgaming.com](mailto:support@kromgaming.com)

### ■ What the warranty does not cover:

1. Any product, on which the serial number has been defaced, modified or removed.
2. Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
3. Repair or attempted repair by anyone not authorized by Nox-xtreme.
4. Damage to or loss of any programs, data or removable storage media.
5. Software or data loss occurring during repair or replacement.
6. Any damage of the product due to shipment.
7. Removal or installation of the product.
8. External causes, such as electric power fluctuations or failure.
9. Use of supplies or parts not meeting kromgaming's specifications.
10. Normal wear and tear.
11. Any other cause which does not relate to a product defect.

For any question, ask us on:



@Krom\_gaming\_



[www.facebook.com/Krom.Gaming.Gear/](https://www.facebook.com/Krom.Gaming.Gear/)